

RP2040 Arduino

Installation CLI

- Download **TBD**
- CLI an einen Pfad kopieren der im Path liegt
`sudo cp arduino-cli /usr/local/bin/`

RP2040 / RP2350

- `nano ~/.arduino15/arduino-cli.yaml`

[arduino-cli.yaml](#)

```
board_manager:  
  additional_urls:  
    -  
    https://github.com/earlephilhower/arduino-pico/releases/download/global/package_rp2040_index.json
```

- Index updaten
`arduino-cli core update-index`
- Core installieren
`arduino-cli core install rp2040:rp2040`
- Board auflisten → `arduino-cli board listall`
Installierte Cores auflisten → `arduino-cli core list`

FQBNs

- Generic RP2040 `rp2040:rp2040:generic rp2040:rp2040`
- Generic RP2350 `rp2040:rp2040:generic_rp2350 rp2040:rp2040`

From:
<https://www.drklipper.de/> - **Dr. Klipper Wiki**

Permanent link:
https://www.drklipper.de/doku.php?id=projekte:sekwai:rp2040_arduino&rev=1754073691

Last update: **2025/08/01 20:41**

