

# Anpassung Pi

- I2C Port fixen
  - `sudo nano /boot/firmware/config.txt`
  - I2C Eintrag anpassen:

```
# Uncomment some or all of these to enable the optional hardware
interfaces
#dtparam=i2c_arm=on
dtoverlay=i2c-
gpio,bus=3,i2c_gpio_sda=3,i2c_gpio_scl=2,i2c_gpio_delay_us=2
```

- STRG+x, Y, Enter

From:

<https://www.drklipper.de/> - **Dr. Klipper Wiki**

Permanent link:

[https://www.drklipper.de/doku.php?id=messy:10\\_devices:wetterstation:02\\_anpassung\\_pi](https://www.drklipper.de/doku.php?id=messy:10_devices:wetterstation:02_anpassung_pi)

Last update: **2024/06/28 09:43**

