



# Raspberry Pi

Raspberry Shop finden → <https://rpilocator.com/>



5V Power	2	5V Power	4	Ground	6	GPI014 UART0_TXD	8	GPI015 UART0_RXD	10	GPI018 PCM_CLK	12	Ground	14	GPI023	16	GPI024	18	Ground	20	GPI025	22	GPI08 SPI0_CEO_N	24	GPI07 SPI0_CEI_N	26	ID_SC I2C ID EEPROM	28	Ground	30	GPI012	32	Ground	34	GPI016	36	GPI020	38	GPI021	
3V3 Power	1	GPI02 SDA1 I2C	3	GPI03 SCL1 I2C	5	GPI04 1-wire	7	Ground	9	GPI017	11	GPI027	13	GPI022	15	3V3 Power	17	GPI010 SPI0_MOSI	19	GPI09 SPI0_MISO	21	GPI011 SPI0_SCLK	23	Ground	25	ID_SD I2C ID EEPROM	27	GPI05	29	GPI06	31	GPI013	33	GPI019	35	GPI026	37	Ground	39



From: <https://www.drklipper.de/> - Dr. Klipper Wiki

Permanent link: [https://www.drklipper.de/doku.php?id=sbc:rasberry\\_pi:start&rev=1695176471](https://www.drklipper.de/doku.php?id=sbc:rasberry_pi:start&rev=1695176471)

Last update: 2023/10/20 09:20

